### § 172.135

- (2) Less than 410 feet (125 meters) in length can survive damage at any location except to an aft machinery space.
- (d) A vessel described in paragraph (b)(2) or (c)(1) of this section need not be designed to survive damage to a main transverse watertight bulkhead bounding an aft machinery space. Except as provided in §153.7 of this chapter, the machinery space must be calculated as a single floodable compartment.

[CGD 79-023, 48 FR 51040, Nov. 4, 1983, as amended by CGD 81-101, 52 FR 7799, Mar. 12, 1987]

## §172.135 Extent of damage.

For the purpose of §172.133-

- (a) Design calculations must include both side and bottom damage, applied separately; and
- (b) Damage must consist of the penetrations having the dimensions given in Table 172.135 except that, if the most disabling penetrations would be less than the penetrations given in Table 172.135, the smaller penetration must be assumed.

## TABLE 172.135—EXTENT OF DAMAGE

COLLISION PENETRATION	
Longitudinal extent	0.495L <sup>2</sup> / <sub>3</sub> or 47.6 feet ((½)L <sup>2</sup> / <sub>3</sub> or
	14.5m) whichever is shorter.
Transverse extent 1	B/5 or 37.74 feet (11.5m) <sup>2</sup> whichever is shorter.
Vertical extent	From the baseline upward with- out limit.
GROUNDING PENETRATION AT THE FORWARD END BUT EXCLUDING ANY DAMAGE AFT OF A POINT 0.3L AFT OF THE FORWARD PERPENDICULAR	
Longitudinal extent	L/10.
Transverse extent	
Vertical extent from the baseline upward.	B/15 or 19.7 feet (6m) whichever is shorter.
GROUNDING PENETRATION AT ANY OTHER LONGITUDINAL POSITION	
Longitudinal extent	L/10 or 16.41 feet (5m) which- ever is shorter.
Transverse extent	16.41 feet (5m).
	B/15 or 19.7 feet (6m) whichever
baseline upward.	
•	d from the vessel's side at right an-

# § 172.140 Permeability of spaces.

(a) When doing the calculations required in §172.130, the permeability of a floodable space other than a machinery space must be as listed in Table 172.060(b).

gles to the centerline at the level of the summer load line assigned under Subchapter E of this chapter.

<sup>2</sup>B is measured amidships.

- (b) Calculations in which a machinery space is treated as a floodable space must be based on an assumed machinery space permeability of 0.85, unless the use of an assumed permeability of less than 0.85 is justified in detail.
- (c) If a cargo tank would be penetrated under the assumed damage, the cargo tank must be assumed to lose all cargo and refill with salt water up to the level of the tankship's final equilibrium waterline.

#### §172.150 Survival conditions.

A tankship is presumed to survive assumed damage if it meets the following conditions in the final stage of flooding:

- (a) Final waterline. The final waterline, in the final condition of sinkage, heel, and trim, must be below the lower edge of openings such as air pipes and openings closed by weathertight doors or hatch covers. The following types of openings may be submerged when the tankship is at the final waterline:
- (1) Openings covered by watertight manhole covers or watertight flush scuttles.
- (2) Small watertight cargo tank hatch covers.
- (3) A Class 1 door in a watertight bulkhead within the superstructure.
- (4) Remotely operated sliding water-tight doors.
- (5) Side scuttles of the non-opening type.
- (b) Heel angle. (1) Except as described in paragraph (b)(2) of this section, the maximum angle of heel must not exceed 15 degrees (17 degrees if no part of the freeboard deck is immersed).
- (2) The Commanding Officer, Marine Safety Center will consider on a case by case basis each vessel 492 feet (150 meters) or less in length having a final heel angle greater than 17 degrees but less than 25 degrees.
- (c) Range of stability. Through an angle of 20 degrees beyond its position of equilibrium after flooding, a tankship must meet the following conditions:
- (1) The righting arm curve must be positive.
- (2) The maximum righting arm must be at least 3.95 inches (10 cm).
- (3) Each submerged opening must be weathertight.